












TREEVOS PRIMA LED

IP66



230V
50/60Hz





TREVOS PRIMA LED


IP66




230V
50/60Hz




6C




7




8




9



10



11



12

Length	Table of maximal number of luminaires in one line			10A B	16A B	10A C	16A C
	Σlm	Σlm	Σlm	Σ	Σ	Σ	Σ
1.2ft	1300	1600	2200	32	50	52	85
1.4ft	2600			32	50	52	85
1.4ft	3200	4400	6400	10	16	16	26
1.5ft	3250	4000	5500	10	16	16	26
1.5ft	8000			10	16	16	26

The light source in this luminaire may be replaced only by the manufacturer or its contractual service technician or similarly qualified person!

Installation can only be carried out by an authorized person and according to the mounting instructions. Any other installation is considered to be improper. For well installation and good luminaire work is necessary ensure a planarity of a mounting surface. Make sure that the luminaire is always disconnected from the power supply before the installation work. Do not use the luminaire if damaged or if damaged the power cable. Only damp microfber cloth can be used for cleaning. Technical changes are subjected without notice. Do not dispose the luminaire or its parts as household waste, but make the proper recycling.